



## Polaris RZR PRO-XP Kicker Installation

Thank you for purchasing our product. Below you will find the steps necessary to properly install your new B&M Fabrications Rock Sliders and Tree Kickers.

1. Remove skid plate.
2. Install the aluminum spacers into all frame openings on the machine.
3. Place kicker against the spacers and install the 7/16" bolts with the small washer on the outside and the large washer on the back side of the frame. Install the flanged nuts.
4. Tighten all mounting bolts.
5. Re install skid plate.



[www.bmfabrications.com](http://www.bmfabrications.com)

612-202-9245